

P25 Decoding

To decode P25 public service channels you will need a few things. The first thing you should read is the tutorial at:

<http://www.rtl-sdr.com/rtl-sdr-radio-scanner-tutorial-decoding-digital-voice-p25-with-dsd/>

This tutorial covers a lot of information and has good links to YouTube videos which explain even more visually.

You will need:

1. Windows computer
2. RTL-SDR dongle with antenna
https://www.amazon.com/dp/B011HVUEME/ref=as_li_ss_tl?ie=UTF8&linkCode=sl1&tag=rsv0f-20&linkId=e6b872ce4bf757ba9f71fbd35a53742e
3. SDR# for Windows 64 bit
<http://airspy.com/download/>
4. VB-Cable virtual audio cable
<http://www.vb-audio.com/Cable/index.htm#DownloadCable>
5. DSD+ P25 decoding software
<https://www.dsdplus.com/download-2/>